


\* These parts are included with the pump.  
All other parts are supplied as part of a pump system,  
or may be ordered separately.

 Denotes areas where thread-sealing tape is required.

### NPT MALE



MPF-1/8QTM	1/8" Quick Test NPT Male
MPF-1/8MPT	1/8" NPT Male
MPF-1/4QTM	1/4" Quick Test NPT Male
MPF-1/4MPT	1/4" NPT Male

Additional NPT sizes available in non-CPF MP adapters

### NPT FEMALE



MPF-1/8QTF	1/8" Quick Test NPT Female
MPF-1/4QTF	1/4" Quick Test NPT Female
MPF-1/4FPT*	1/4" NPT Female
MPF-1/2QTF	1/2" Quick Test NPT Female


Additional NPT sizes available in non-CPF MP adapters

### BSP



MPF-1/8BSPF	G 1/8" Female
MPF-1/4BSPF	G 1/4" Female
MPF-3/8BSPF	G 3/8" Female
MPF-1/2BSPF	G 1/2" Female

### TRANSMITTER




MPF-5/16TRM	for Foxboro, Rosemount, & Yokogawa
MPF-1/4TRM	for Honeywell

### TUBE



MPF-1/4TBM	1/4" Tube Male
MPF-3/8TBM	3/8" Tube Male
MPF-1/2TBM	1/2" Tube Male

### CPF



MPF-MPF	Female to Female
MPF-MPF TU	T-Union (Female)
MPF-MPF BULK	Bulkhead (Female to Female)
MPF-CAP	Cap

### ADDITIONAL



MPF-M20QTF	M20 x 1.5 Quick Test Female
MPF-M20X1.5F	M20 x 1.5 Female
MPF-QCN	Quick-Connect Nut
MPF-AN4M	AN4 Male